

Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per Nikon Z 30 + 12-28mm o cerca il tuo prodotto tra le migliori offerte di Fotocamere



Questo manuale d'istruzione è fornito da trovaprezzi.it. Scopri tutte le offerte per Nikon Z 30 + 16-50mm o cerca il tuo prodotto tra le migliori offerte di Fotocamere

Nikon

with **WARRANTY**



Read this document thoroughly before using the camera. • To ensure proper use of the camera, be sure to read "For your safety" (overleaf).

- · After reading this document, keep it readily accessible for future reference.
- No reproduction in any form of this document, in whole or in part (except for brief quotation in

critical articles or reviews), may be made without written authorization from NIKON CORPORATION.

NIKON CORPORATION

© 2022 Nikon Corporation

()



Warranty terms - Nikon Europe service warranty Dear Nikon custome

We thank you for your purchasing this Nikon product. Should your Nikon product require warranty service, please contact the dealer from whom it was purchased or a member of our authorized service network within the sales territory of Nikon Europe B.V. (e.g. Europe/Russia/others). See details under: https://www.europe-nikon.com/support

In order to avoid any unnecessary inconvenience, we advise you to read the user manuals carefully before contacting the dealer or our authorized service network. Your Nikon equipment is guaranteed against any manufacturing defects for one full year from the date of original purchase. If during this period of guarantee the product proves defective due to improper material or workmanship, our authorized service network within the sales territory of Nikon Europe B.V. will, without charge for labor and parts, repair the product in the terms and conditions set as below. Nikon reserves the right (at its sole discretion) to replace or repair the product.

- 1. This warranty is only provided upon presentation of the completed warranty card and original invoice or purchase receipt indicating the date of purchase, product type and dealer's name, together with the product. Nikon reserves the right to refuse free-of-charge warranty service if the above documents cannot be presented or if the information contained in it is incomplete or illegible.
- 2. This warranty will not cover: necessary maintenance and repair or replacement of parts due to normal wear and tear.
- modifications to upgrade the product from its normal purpose as described in user manuals, without the prior written consent of Nikon.
- transport costs and all risks of transport relating directly or indirectly to the warranty of the products.
- any damage resulting from modifications or adjustments which may be made to the product, without the prior written consent of Nikon, in order to comply with local or national technical standards in force in any other country than the ones for which the product was originally designed and/or manufactured.

3. The warranty will not be applicable in the case of:

- damage caused by misuse including but not limited to failure to use the product for its normal purpose or according to the user instructions on the proper use and maintenance, and to installation or use of the product inconsistent with the safety standards in force in the country where it is used. · damage caused by accidents including but not limited to lightning, water, fire, misuse or neglect.
- · defacing, illegibility or removal of the model or serial number on the product · damage resulting from repairs or adjustments which have been conducted
- by unauthorized service organizations or persons. • defects in any system into which the product is incorporated or with which it is used.
- 4. This service warranty does not affect the consumer's statutory rights under applicable national laws in force, nor the consumer's right against the dealer arising from their sales/purchase contract.
- Notice: An overview of all authorized Nikon Service Stations can be found online by following this Link

(URL = https://www.europe-nikon.com/service/).

Printed in Thailand 6MO04511-02

🔽 Lens kit lenses For information on lenses supplied as part of a lens kit, see the lens documentation available for download from the Nikon Download Center. The Nikon Download Center Visit the Nikon download center to download the latest firmware for cameras and lenses. NX Studio and other

Z 30 Model Name: N2121

offer a number of options

For users in the U.S.A.

For users in Canada:

For users in Mexico:

For users in Europe:

support

https://www.nikon.ca/

https://www.nikonusa.com/

https://www.nikon.com.mx/

https://www.europe-nikon.com/

• For users in Asia, Oceania, the

Middle East, and Africa:


https://www.nikon-asia.com/

https://www.nikonamericalatina.com/

For users in Latin America:

Should you need technical support, we

Nikon user support




Package contents

- Be sure all items listed here were included with your camera.
- Camera BF-N1 body cap

battery

- Strap U Warranty (see left) User's Manual (this sheet) EN-EL25 rechargeable Li-ion
- UC-E24 USB cable Memory cards are sold separately.
- Purchasers of the lens kit option should confirm that the package also includes a lens
- This camera uses SD, SDHC, and SDXC memory cards, referred to throughout this document as "memory cards".

Parts of the camera





The Z 30 User's Manual and Reference Guide

In addition to this User's Manual, a Reference Guide is available

Q

The User's Manual describes basic camera operations.

Camera features and operations are detailed in

a *Reference Guide*, a supplement to the *User's*

Manual. The Reference Guide can be viewed on

computers, smartphones, and tablets.

https://onlinemanual.nikonimglib.com/z30/en/

for your camera.

III The Reference Guide


The User's Manual (this sheet)

nikon reference guide Z 30

First steps

Attaching the strap

To attach a strap (whether the supplied strap or one that has been purchased separately):




Turn the camera off before inserting or removing the battery and

- memory card. Using the battery to keep the orange battery latch pressed to one side, slide the battery into the battery chamber until the latch locks it in place.
- Holding the memory card in the orientation shown, slide it straight into the slot until it clicks into place.



Charging the battery


- Fully charge the supplied EN-EL25 battery before use. With the battery inserted in the camera, connect the camera with a computer using the supplied USB cable to charge.
- Battery care Read and follow the warnings and cautions in "For your safety" (overleaf) and "Caring for the camera and battery: Cautions" (overleaf).
- Insert the EN-EL25 into the



camera


39 Memory card access lamp 40 Battery-chamber/memory card Battery-chamber/memory card

source.



Remove the front lens cap before taking pictures.

- 🔽 F mount lenses Be sure to attach the FTZ II/FTZ mount adapter (available separately) before using F mount lenses. Attempting to attach F mount lenses directly to the camera could damage the lens or image sensor.
- Detaching lenses • After turning the camera off, press and hold the lens release button while turning the lens in the direction opposite that of
- attachment to detach the lens. After removing the lens, replace the lens caps and camera body cap.



- Highlight the desired date (year, month, and day) display order and • The [Daylight saving time] screen will be displayed.
- **5** Turn daylight saving time on or off. • Highlight [**On**] (daylight saving time on) or [**Off**] (daylight saving time off) and press . • Selecting [**On**] advances the clock
- one hour; to undo the effect, select [Off]. • The [Date and time] screen will be displayed.
- Press ④ or ④ to highlight date and time items and press 🕭 or 🝚 to
- change them. • Press
 to confirm the date and time setting.
- The message [**Done.**] will be displayed and the camera switches to shooting mode.

умрнм s


20 22. 10. 15 00:00:00


Taking photographs easily (a auto) Lenses with retractable barrels enses with retractable barrels must be extended before use. Rotate the zoom ring as shown until the lens clicks into the Select photo mode by rotating the photo/video selector to 🗅. 2 Rotate the mode dial to 🗃. adura **3** Ready the camera. 4 Frame the photograph. 89 OK):

- **5** Press the shutter-release button halfway to focus.
- **6** Smoothly press the shutter-release button the rest of the way down to take the photograph.

Recording videos easily (and auto)

- Select video mode by rotating the photo/video selector to 塛.
- **2** Rotate the mode dial to
- **3** Press the video-record button to start recording.





((MENU))

 \subseteq

4 Press the video-record button again to end recording.

Viewing photos

- Press the 🕨 button to view photos and videos recorded with the camera on the monitor.
- Press ④ or ④, or flick left or right on the monitor to view other images.
- Videos are indicated by a \makebox icon at the upper left of the monitor. Press the
 button, or tap the
 icon in the monitor to play back videos
- To end playback and return to shooting mode, press the shutterrelease button halfway.

Caring for the camera

Storage When the camera will not be used for an extended period, remove the battery. Before removing the battery, confirm that the camera is off. Do not store the camera in locations that • are poorly ventilated or subject to humidities of over 60% • are next to equipment that produces strong electromagnetic fields, such as televisions or radios are exposed to temperatures above 50 °C (122 °F) or below -10 °C (14 °F) Troubleshooting You may be able to resolve any issues with the camera by following the steps below. Check this list before consulting your retailer or Nikonauthorized service representative. Check the list of common problems. **STEP 1** Common problems and solutions are listed in the troubleshooting section of the Reference Guide. Turn the camera off and remove the battery, then wait about a minute, reinsert the battery and turn the camera on **STEP 2** The camera may continue to write data to the memory card after shooting. Wait at least a minute before removing the batterv. Search Nikon websites. • For support information and answers to frequently asked questions, visit the website for your country or region (see STEP 3 "Nikon user support" at the top left corner of this page). To download the latest firmware for your camera, visit: https://downloadcenter.nikonimglib.com/ STEP 4 Consult a Nikon-authorized service representative

For your safety

To prevent damage to property or injury to yourself or to others, read "For your safety" in its entirety before using this produ After reading these safety instructions, keep them readily accessible for future

A DANGER: Failure to observe the precautions marked with this icon carries a high risk of death or severe injury MARNING: Failure to observe the precautions marked with this icon could result in

death or severe injury. \bigwedge CAUTION: Failure to observe the precautions marked with this icon could result in

injury or property damage.

MARNING

Do not use while walking or operating a vehicle. ailure to observe this precaution could result in accidents or other injury. Do not disassemble or modify this product. Do not touch internal parts that

become exposed as the result of a fall or other accident. Failure to observe these precautions could result in electric shock or other injury. Should you notice any abnormalities such as the product producing smoke, heat, or unusual odors, immediately disconnect the battery or power source

Continued operation could result in fire, burns or other injury. Keep dry. Do not handle with wet hands. Do not handle the plug with wet hands.

Failure to observe these precautions could result in fire or electric shock Do not let your skin remain in prolonged contact with this product while it is on or plugged in.

Failure to observe this precaution could result in low-temperature burns. Do not use this product in the presence of flammable dust or gas such as propane, gasoline or aerosols

Failure to observe this precaution could result in explosion or fire. Do not directly view the sun or other bright light source through the lens.

Failure to observe this precaution could result in visual impairme Do not aim the flash at the operator of a motor vehicle.

Failure to observe this precaution could result in accidents.

Keep this product out of reach of children.

Failure to observe this precaution could result in injury or product malfunction. In addition, note that small parts constitute a choking hazard. Should a child swallow any part of this product, seek immediate medical attention.

Do not entangle, wrap or twist the straps around your neck

Failure to observe this precaution could result in accidents.

Do not use batteries, chargers, AC adapters, or USB cables not specifically designated for use with this product. When using batteries, chargers, AC

adapters, and USB cables designated for use with this product, do not

 Damage, modify, forcibly tug or bend the cords or cables, place them under heavy objects, or expose them to heat or flame. Use travel converters or adapters designed to convert from one voltage to

another or with DC-to-AC inverters. Failure to observe these precautions could result in fire or electric shock.

Do not handle the plug when charging the product or using the AC adapter during thunderstorr

ailure to observe this precaution could result in electric shock

Dust on or near the metal parts of the plug should be removed with a dry cloth. Continued use could result in fire

Do not handle with bare hands in locations exposed to extremely high or low

Failure to observe this precaution could result in burns, or frostbite

Do not leave the lens pointed at the sun or other strong light sources. Light focused by the lens could cause fire or damage to product's internal parts. When shooting backlit subjects, keep the sun well out of the frame. Sunlight focused into the camera when the sun is close to the frame could cause fire

Turn this product off when its use is prohibited. Disable wireless features when the use of wireless equipment is prohibited.

The radio-frequency emissions produced by this product could interfere with equipment onboard aircraft or in hospitals or other medical facilities

Remove the battery and disconnect the AC adapter if this product will not be used for an extended period

Failure to observe this precaution could result in fire or product malfunction. Do not fire the flash in contact with or in close proximity to the skin or objects. Failure to observe this precaution could result in burns or fire.

Do not leave the product where it will be exposed to extremely high emperatures, for an extended period such as in an enclosed automobile or in

direct sunlight. Failure to observe this precaution could result in fire or product malfunction Do not look at the REC lamp from short distances or for long periods. ailure to observe this precaution could have adverse effects on vision

Do not transport cameras or lenses with tripods or similar accessories attached. Failure to observe this precaution could result in injury or product malfunction.

DANGER (Batteries)

Do not mishandle batteries.

Failure to observe the following precautions could result in the batteries leaking, overheating, rupturing, or catching fire:

Use only rechargeable batteries approved for use in this product.

Do not expose batteries to flame or excessive heat Do not disassemble

Do not short-circuit the terminals by touching them to necklaces, hairpins, or other

metal objects. Do not expose batteries or the products in which they are inserted to powerful

physical shocks. Do not step on batteries, pierce them with nails, or strike them with hammers.

Charge only as indicated.

Failure to observe this precaution could result in the batteries leaking, overheating,

rupturing, or catching fire. If battery liquid comes into contact with the eyes, rinse with plenty of clean water

and seek immediate medical attention

Follow the instructions of airline personnel.

Batteries left unattended at high altitudes in an unpressurized environment may

leak, overheat, rupture, or catch fire.

/! WARNING (Batteries)

Keep batteries out of reach of children. Should a child swallow a battery, seek immediate medical attention Keep batteries out of reach of household pets and other animals The batteries could leak, overheat, rupture, or catch fire if bitten, chewed, or

otherwise damaged by animals. Do not immerse batteries in water or expose to rain

Failure to observe this precaution could result in fire or product malfunction. mmediately dry the product with a towel or similar object should it become wet Discontinue use immediately should you notice any changes in the batteries, such as discoloration or deformation. Cease charging EN-EL25 rechargeable batteries if they do not charge in the specified period of time.

Failure to observe these precautions could result in the batteries leaking. overheating, rupturing, or catching fire.

When batteries are no longer needed, insulate the terminals with tape. Overheating, rupture, or fire may result should metal objects come into contact with

If battery liquid comes into contact with a person's skin or clothing, immediately rinse the affected area with plenty of clean water. Failure to observe this precaution could result in skin irritation

Notices

 No part of the documentation included with this product may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without Nikon's prior written permission • Nikon reserves the right to change the appearance and specifications of the hardware

and software described in this documentation at any time and without prior notice. Nikon will not be held liable for any damages resulting from the use of this product. While every effort has been made to ensure that the information in this documentation is accurate and complete, we would appreciate it were you to bring any errors or omissions

to the attention of the Nikon representative in your area (address provided separately). Notice concerning prohibition of copying or reproduction Note that simply being in possession of material that has been digitally copied or reproduced

by means of a scanner, digital camera, or other device may be punishable by law.

Items prohibited by law from being copied or reproduced

Do not copy or reproduce paper money, coins, securities, government bonds, or local government bonds, even if such copies or reproductions are stamped "Sample". The copying or reproduction of paper money, coins, or securities which are circulated in a foreign country is prohibited.

Unless the prior permission of the government has been obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited.

The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.

Cautions on certain copies and reproductions

The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes, or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards, and tickets, such as passes and meal coupons.

Comply with copyright notices

Under copyright law, photographs or recordings of copyrighted works made with the camera cannot be used without the permission of the copyright holder Exceptions apply to personal use, but note that even personal use may be restricted in the case of photographs or recordings of exhibits or live performances.

Use only Nikon brand electronic accessories

Nikon cameras are designed to the highest standards and include complex electronic circuitry. Only Nikon brand electronic accessories (including lenses, battery chargers, batteries, AC adapters, and flash accessories) certified by Nikon specifically for use with this Nikon digital camera are engineered and proven to operate within the operational and safety requirements of this electronic circuitry.

The use of non-Nikon electronic accessories could damage the

camera and may void your Nikon warranty. The use of third-party rechargeable Li-ion batteries not bearing the Nikon holographic seal

shown at right could interfere with normal operation of the camera or

result in the batteries overheating, igniting, rupturing, or leaking.

For more information about Nikon brand accessories, contact a local authorized Nikon dealer

Memory cards

· Memory cards may be hot after use. Observe due caution when removing memory cards from the camera.

· Do not perform the following operations during formatting or while data are being recorded, deleted, or copied to a computer or other device. Failure to observe these precautions could result in loss of data or in damage to the camera or card.

- Do not remove or insert memory cards
- Do not turn the camera off
- Do not remove the battery
- Do not touch the card terminals with your fingers or metal objects. · Do not use excessive force when handling memory cards. Failure to observe this precaution could damage the card.
- Do not bend or drop memory cards or subject them to strong physical shocks. · Do not expose memory cards to water, heat, or direct sunlight
- · Do not format memory cards in a computer.

Before taking important pictures

Before taking pictures on important occasions (such as at weddings or before taking the camera on a trip), take a test shot to ensure that the camera is functioning normally. Nikon will not be held liable for damages or lost profits that may result from product malfunction.

Life-long learning

As part of Nikon's "Life-long learning" commitment to ongoing product support and education, continually-updated information is available on-line at the following sites:

For users in the U.S.A.: https://www.nikonusa.com/

- For users in Canada: <u>https://www.nikon.ca/</u>
- For users in Mexico: <u>https://www.nikon.com.mx/</u>
- For users in Latin America: https://www.nikonamericalatina.com/ For users in Europe: <u>https://www.europe-nikon.com/support/</u>
- For users in Asia, Oceania, the Middle East, and Africa: https://www.nikon-asia. com

Visit these sites to keep up-to-date with the latest product information, tips, answers to frequently-asked questions (FAQs), and general advice on digital imaging and photography. Additional information may be available from the Nikon representative in your area. See the following

URL for contact information: https://imaging.nikon.com/ Notices for customers in Europe

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

The following apply only to users in European countries:

collection point. Do not dispose of as household waste.

The following apply only to users in European countries

This symbol indicates that electrical and electronic equipment is to be

This product is designated for separate collection at an appropriate

· For more information, contact the retailer or the local authorities in

This symbol on the battery indicates that the battery is to be collected

• All batteries, whether marked with this symbol or not, are designated for separate collection at an appropriate collection point. Do not dispose of

For more information, contact the retailer or the local authorities in

Separate collection and recycling helps conserve natural resources and

prevent negative consequences for human health and the environment

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

that might result from incorrect disposal.

charge of waste management.

charge of waste management

as household waste.

collected separately.

separately.

Battery care Precautions for use

Caring for the camera and battery: Cautions

Do not drop the camera or lens or subject them to blows. The product may

Keep the camera dry. Rusting of the internal mechanism caused by water

inside the camera can not only be expensive to repair but can in fact cause

If you bring the camera from a cold place to a warm place, or from a warm

place to a cold place, water droplets may form inside and outside the

camera and cause damage. When you bring the camera to a place with

a temperature difference, place the camera in a carrying case or plastic

bag and seal it beforehand. When the camera has adapted to the ambient

Static charges or the magnetic fields produced by equipment such as radio

transmitters could interfere with the monitor, corrupt data stored on the

Do not leave the lens pointed at the sun or other strong light source for

extended periods. Intense light may damage the image sensor or cause

fading or "burn in". Photographs taken with the camera may exhibit a white

Do not direct lasers or other extremely bright light sources toward the lens,

When cleaning the camera body, use a blower to gently remove dust and

lint, then wipe gently with a soft, dry cloth. After using the camera at the

beach or seaside, wipe off any sand or salt using a cloth lightly dampened

This glass element is easily damaged: remove dust and lint with a blower. If

using an aerosol blower, keep the can vertical to prevent the discharge of

stains from the lens, apply a small amount of lens cleaner to a soft cloth

Keep the lens contacts clean. Avoid touching them with your fingers.

To prevent mold or mildew, store the camera in a dry, well-ventilated

area. Do not store the camera with naphtha or camphor moth balls, next

to equipment that produces strong electromagnetic, or where it will be

in an enclosed vehicle on a hot day. Failure to observe these precautions

To prevent damage caused by, for example, leaking battery fluid, remove

the camera in a plastic bag containing a desiccant. Do not, however, store

the battery if the product will not be used for an extended period. Store

the leather camera case in a plastic bag, as this may cause the material

to deteriorate. Store the battery in a cool, dry place. Note that desiccant

storage at least once a month, insert the battery, and release the shutter a

Removing the battery while the camera is on could damage the product.

Particular care should be taken not to remove or disconnect the power

• The monitor is constructed with extremely high precision; at least

Images in the monitor may be difficult to see in a bright light.

does not touch the skin or enter the eves or mouth.

Discontinue use until your condition improves.

Bright lights and back-lit subjects

bright lights or back-lit subjects.

Disposing of data storage devices

data is the user's responsibility.

information.

99.99% of pixels are effective, with no more than 0.01% being missing or

defective. Hence while the monitor may contain pixels that are always lit

(white, red, blue, or green) or always off (black), this is not a malfunction.

Images recorded with the device are unaffected. Your understanding is

• Do not apply pressure to the monitor. The monitor could malfunction or

suffer damage. Dust or lint on the monitor can be removed with a blower.

chamois leather. Should the monitor break, care should be taken to avoid

flickering display could cause you to feel unwel

Stains can be removed by wiping the monitor lightly with a soft cloth or

injury from broken glass. Be careful that liquid crystal from the monitor

The display may rapidly flicker on and off during burst photography.

Noise in the form of lines may in rare cases appear in pictures that include

Please note that deleting images or formatting memory cards or other

data. Deleted files can sometimes be recovered from discarded storage

devices using commercially available software, potentially resulting in

the malicious use of personal image data. Ensuring the privacy of such

Before discarding a data storage device or transferring ownership to

another person, erase all data using commercial deletion software, or

format the device and then completely refill it with images containing

be taken to avoid injury when physically destroying data storage

devices. Before discarding the camera or transferring ownership to

another person, you should also use the [Reset all settings] item in the camera setup menu to delete network settings and other personal

no private information (for example, pictures of empty sky). Care should

data storage devices does not completely erase the original image

gradually loses its capacity to absorb moisture and should be replaced

at regular intervals. To prevent mold or mildew, take the camera out of

• Turn the product off before removing the battery

source while images are being recorded or deleted.

exposed to extremely high temperatures, for example near a heater or

liquid that could damage glass elements. To remove fingerprints and other

malfunction if subjected to strong shocks or vibration.

Avoid sudden changes in temperature

temperature, take it out from the bag and use it.

memory card, or affect the product's internal circuitry.

Keep away from strong magnetic fields

Do not leave the lens pointed at the sun

• Lasers and other bright light sources

as this could damage the camera's image sensor

in fresh water and then dry the camera thoroughly.

Camera care

Keep dry

blur effect.

Cleaning

Cleaning the lens

and wipe the lens carefully

• The lens contacts

Long-term storage

Notes on the monitor

requested.

few times.

Do not touch the image sensor

Store in a well-ventilated area

could result in product malfunction.

Under no circumstances should you exert

pressure on the image sensor, poke it with

cleaning tools, or subject it to powerful air

currents from a blower. These actions could

scratch or otherwise damage the sensor.

irreparable damage

• Do not drop

• If improperly handled, batteries may rupture or leak, causing the product to corrode. Observe the following precautions when handling batteries: Turn the product off before replacing the battery.

Batteries may be hot after extended use.

Keep the battery terminals clean.

Use only batteries approved for use in this equipment. Do not short or disassemble batteries or expose them to flame or

excessive heat.

When the battery is not inserted in the camera, insulate the terminals. If there is a terminal cover, attach the terminal cover to the battery. If there is no terminal cover, keep the battery separate in a plastic bag or other non-conductive container.

If the battery is hot, for example immediately after use, wait for it to cool before charging. Attempting to charge the battery while its internal temperature is elevated will impair battery performance, and the battery may not charge or charge only partially.

If the battery will not be used for some time, remove it from the camera for storage. The battery should be stored in a cool, dry location with an ambient temperature of 15 °C to 25 °C (59 °F to 77 °F). Avoid hot or extremely cold locations.

Batteries should be charged within six months of use. During long periods of disuse, charge the battery once every six months before returning it to a cool location for storage.

Remove the battery from the camera when not in use. The camera and charger draw minute amounts of charge even when off and could draw the battery down to the point that it will no longer function.

Do not use the battery at ambient temperatures below 0 °C (32 °F) or above 40 °C (104 °F). Failure to observe this precaution could damage the battery or impair its performance. Charge the battery indoors at ambient temperatures of 5 °C–35 °C (41 °F–95 °F). The battery will not charge if its temperature is below 0 °C (32 °F) or above 60 °C (140 °F).

Capacity may be reduced and charging times increase at battery temperatures from 0 °C (32 °F) to 15 °C (59 °F) and from 45 °C (113 °F) to 60 °C (140 °F).

Batteries in general exhibit a drop in charging capacity at low ambient temperatures.

Batteries in general exhibit a drop in available capacity at low ambient temperatures. The change in capacity with temperature is reflected in the camera battery-level display. As a result, the battery display may show a drop in capacity as the temperature drops, even if the battery is fully

Batteries may be hot after use. Observe due caution when removing batteries from the camera

• Charge batteries before use

Charge the battery before use. The supplied battery is not fully charged at

Ready spare batteries

charged

shipment.

performance.

Before taking photographs, ready a spare battery and keep it fully charged. Depending on your location, it may be difficult to purchase replacement batteries on short notice.

• Have fully-charged spare batteries ready on cold days

Partially-charged batteries may not function on cold days. In cold weather, charge one battery before use and keep another in a warm place, ready to be exchanged as necessary. Once warmed, a cold battery may recover some of its charge.

Batterv level • Turning the camera on or off repeatedly when the battery is fully discharged will shorten battery life. Batteries that have been fully

discharged must be charged before use. · A marked drop in the time a fully charged battery retains its charge when used at room temperature indicates that it requires replacement.

Purchase a new rechargeable battery

• Do not attempt to charge fully-charged batteries Continuing to charge the battery after it is fully charged can impair battery

Recycling used batteries

Recycle rechargeable batteries in accord with local regulations, being sure to first insulate the terminals with tape.

Trademarks and licenses

• The SD, SDHC, and SDXC logos are trademarks of SD-3C, LLC

Windows is either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries

Apple®, App Store®, the Apple logos, iPhone®, iPad®, Mac, and macOS are trademarks of Apple Inc. registered in the U.S. and/or other countries

Android, Google Play and the Google Play logo are trademarks of Google LLC. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. IOS is a trademark or registered trademark of Cisco Systems, Inc., in the United States

and/or other countries and is used under license HDMI, the HDMI logo and High-Definition Multimedia Interface

ноті are trademarks or registered trademarks of HDMI Licensing, LLC. The Bluetooth® word mark and logo are registered trademarks owned by Bluetooth

SIG, Inc., and any use of such marks by Nikon is under license. Wi-Fi and the Wi-Fi logo are trademarks or registered trademarks of the Wi-Fi Alliance.
 All other trade names mentioned in this document or the other documentation provided with your Nikon product are trademarks or registered trademarks of their respective holders.

Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple products identified in the badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with an Apple product may affect wireless performance.

The software for this product includes open-source software copyrighted by third parties. The terms of the licenses for this open-source software may be found in the Reference Guide.

https://downloadcenter.nikonimglib.com/

Bluetooth and Wi-Fi (wireless LAN)

This product is controlled by the United States Export Administration Regulations (EAR). The permission of the United States government is not required for export to countries other than the following, which as of this writing are subject to embargo or special controls: Cuba, Iran, North Korea, Sudan, and Syria (list subject to change). The use of wireless devices may be prohibited in some countries or regions Familiarize yourself with and obey all applicable local regulations

The Bluetooth transmitter in this device operates in the 2.4 GHz band

Notice for customers in Europe and in countries complying with the Radio Equipment Directive Hereby, Nikon Corporation declares that the radio equipment type Z 30 s in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the ollowing internet address

https://imaging.nikon.com/support/pdf/DoC_N2121.pdf Wi-Fi

Operating frequency:

- 2412-2462 MHz (channel 11; Africa, Asia, Bolivia, Europe, and Oceania) - 2412–2462 MHz (channel 11), 5180–5825 MHz (5180–5580 MHz, 5660–5700 MHz

- and 5745-5825 MHz) (U.S.A., Canada, Mexico) 2412-2462 MHz (channel 11), 5180-5805 MHz (5180-5320 MHz and
- 5745–5805 MHz) (other countries in the Americas)
- Maximum output power (EIRP): - 2.4 GHz band: 4.5 dBm
- 5 GHz band: 6.8 dBm (countries in the Americas)

Bluetooth

• **Operating frequency:** - Bluetooth: 2402–2480 MHz

Bluetooth Low Energy: 2402–2480 MHz Maximum output power (EIRP): - Bluetooth: -1.0 dBm

Bluetooth Low Energy: -2.5 dBm

Notice for customers in the UK

Hereby, Nikon Corporation declares that the radio equipment type Z 30 is in compliance with Radio Equipment Regulations 2017.

The full text of the UKCA declaration of conformity is available at the following internet address

https://imaging.nikon.com/support/pdf/UKCA_DoC_N2121.pdf Wi-Fi

Operating frequency:

- 2412-2462 MHz (channel 11) Maximum output power (EIRP):

- 2.4 GHz band: 4.5 dBm Bluetooth

Operating frequency:

Bluetooth: 2402–2480 MHz Bluetooth Low Energy: 2402–2480 MHz

Maximum output power (EIRP):

Bluetooth: -1.0 dBr - Bluetooth Low Energy: –2.5 dBm

Conformity marking

Some of the information related to standards with which the camera complies can be viewed using the [Conformity marking] option in the setup menu.



LE



