


ozone NEON M10

OPTICAL PRO GAMING MOUSE



QUICK GUIDE

IT'S ALL ABOUT **EVOLUTION**

NEON **M10**


SYSTEM **REQUIREMENTS**

1. Operation System
Windows and Mac
2. Free **USB** 2.0 port

INSTALLATION **INSTRUCTIONS**

1. Plug USB connector of Neon M10 to a USB port of your PC
2. Wait until your system detects, configures the plug and play device and finishes the installation
3. Enjoy gaming with Neon M10

BUTTONS LAYOUT



DEFAULT BUTTON ASSIGNMENT

- 1 - Click
- 2 - Menu
- 3 - Wheel Click
- 4 - Cpi Cycle
- 5 - IE Forward (Right hand user mode)
- 6 - IE Backward (Right hand user mode)
- 7 - IE Forward (Left hand user mode)
- 8 - IE Backward (Left hand user mode)
- 9 - Scroll Up
- 10 - Scroll Down

WITHIN THE GAME

ON-THE-FLY ADJUSTMENT

Use this combo buttons to adjust the Neon M10 features.

LEFT HANDED USER:

LEFT BUTTON + DPI BUTTON FOR 5 SECONDS

RIGHT HANDED USER:

RIGHT BUTTON + DPI BUTTON FOR 5 SECONDS

DPI ADJUSTMENT:

DPI BUTTON

REPORT RATE ADJUSTMENT:

LEFT BUTTON + RIGHT BUTTON + SCROLL CLICK FOR 5 SECONDS

WEEE NOTICE:

Symbol for Separate Collection in European Countries.
This symbol indicates that this product is to be collected separately.
The following apply only to users in European countries:



This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.

For more information, contact the retailer or the local authorities in charge of waste management.

©2014 OZONE Gaming Gear. All rights reserved.



ozone

it's all about **EVOLUTION**

www.ozonegaming.com