


Schubkarre



rolly toys Kundendienst Deutschland:

Tel: +49 (0) 95 68 / 856-142









Fax: +49 (0) 95 68 / 856-183

e-mail: service@rollytoys.de



2017/02


184.000.801.00



---NORTH & SOUTH AMERICA only---

180 days warranty


From the date of purchase + guaranteed spare part service
The warranty does not cover damages caused by improper use or neglect



Franz Schneider GmbH & Co KG
P.O.Box 1460
D-96459 · Neustadt bei Coburg · Germany
Tel.: +49 (0) 95 68 / 856-0
Fax.: +49 (0) 95 68 / 856-190
www.rollytoys.com




ROLLY TOYS ITALIANA SRL
Via Colonna 9
I-31025 · Santa Lucia Di Piave · Italy

→ **		
● +10	● +26	● +47
● +12	● +30	● +51
● +13	● +37	● +54
● +20	● +38	● +60
● +22	● +40	● +70
● +23	● +41	● +75
● +25	● +44	● +80



WARNING

- **CHOKING HAZARD:** Small parts, Danger of being swallowed. Contains small parts in non assembled state. Must be assembled by adults.
- Adult supervision required.
- Never use near steps, slopes, driveways, hills, roadways, alleys or swimming pool areas.
- Always wear shoes.
- Article not suitable to carry children.
- Conforms to the requirements of ASTM Standard Consumer Safety Specification on Toy Safety, F 963



- **Achtung Stopmutter (selbstsichernde Mutter) !**
Wenn fest, noch weiter drehen.
- **Please note: stop nut (self-locking nut)!**
Continue to turn when tight.
- **Attention Écrou d'arrêt (Écrou autobloquant) !**
Continuer à tourner s'il est fixe.
- **Attenzione dado di arresto (autobloccante) !**
Continuare a serrare dopo il primo bloccaggio.

