



SONY




1




SRS-XB12




* 4 7 4 6 1 3 6 1 1 * (1)






DC IN 5V




CHG 04h:30m CHG



2




ON PAIRING 3s




Bluetooth





Android™ iPhone









BLUETOOTH ON SRS-XB12



3



http://rd1.sony.net/help/speaker/srs-xb12/h_zz/



Android iPhone

