

SONY

Wireless Stereo Headset Casque stéréo sans fil

4-747-578-13(1)

Reference Guide
Manuel de référence
Guía de referencia

US
FR
ES



http://rd1.sony.net/help/mdr/whxb700/h_zz/

Made for
iPhone | iPod

Conçu pour
iPhone | iPod



©2019 Sony Corporation
Printed in China
Imprimé en Chine
<http://www.sony.net/>

WH-XB700

English

Wireless Stereo Headset

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time.

Do not dismantle, open or shred secondary cells or batteries.

Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.

In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Secondary cells and batteries need to be charged before use. Always refer to the manufacturer's instructions or equipment manual for proper charging instructions.

After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.

Dispose of properly.

RECYCLING RECHARGEABLE BATTERIES
Rechargeable batteries are recyclable. You can help preserve our environment by returning your used rechargeable batteries to the collection and recycling location nearest you.

For more information regarding recycling of rechargeable batteries, visit <http://www.sony.com/electronics/eco/environmental-management>.

Caution: Do not handle damaged or leaking rechargeable batteries.

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that is deemed to comply without testing of specific absorption rate (SAR).

FOR UNITED STATES CUSTOMERS. NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF QUEBEC.

POUR LES CONSOMMATEURS AUX ETATS-UNIS. NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

If you have any questions about this product:

Visit: www.sony.com/support
Contact: Sony Customer Information Service Center at 1-800-222-7669

Write: Sony Customer Information Service Center 12451 Gateway Blvd., Fort Myers, FL 33913

Supplier's Declaration of Conformity

Trade Name : SONY

Model : WH-XB700

Responsible Party : Sony Electronics Inc.

Address : 16535 Via Espriola, San Diego, CA 92127 U.S.A.

Telephone Number : 858-942-2230

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that is deemed to comply without testing of specific absorption rate (SAR).

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This equipment must not be co-located or operated in conjunction with any other antenna or transmitter.

For the customer in Canada
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference; and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

High volume may affect your hearing.
Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

Do not use at a dangerous place unless the surrounding sound can be heard.

The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately and consult your nearest Sony dealer. In particular, be careful in the following cases.

- When using the unit around a sink, etc.
Be careful that the unit does not fall into a sink or container filled with water.
- When using the unit in the rain or snow, or in humid locations
- When using the unit while you are sweaty
If you touch the unit with wet hands, or put the unit in the pocket of a damp article of clothing, the unit may get wet.

For details on the effect of contact to the human body from the mobile phone or other wireless devices connected to the unit, refer to the instruction manual of the wireless device.

Never insert the USB plug when the main unit or charging cable is wet. If the USB plug is inserted while the main unit or charging cable is wet, a short circuit may occur due to the liquid (tap water, seawater, soft drink, etc.) attached to the main unit or charging cable or due to foreign matter, and cause abnormal heat generation or malfunction.

Note on static electricity
Static electricity accumulated in the body may cause mild tingling in your ears. To reduce the effect, wear clothes made from natural materials, which suppress the generation of static electricity.

IMPORTANT: THE FACTORY DEFAULT SETTING OF THE VOICE GUIDEANCE FOR THIS UNIT IS ENGLISH.

The voice guidance can be heard from the unit when:

• When powering on: "Power on"

• When powering off: "Power off"

• When the remaining battery level is low and recharge is recommended:

"Low battery, please recharge headset"

• When automatically turning off due to low battery: "Please recharge headset. Power off"

• When checking the remaining battery level by pressing the POWER button while the unit turns on: "Battery fully charged" / "Battery about 70%" / "Battery about 50%" / "Battery about 20%"

• When entering pairing mode: "Bluetooth pairing"

• When establishing a Bluetooth connection: "Bluetooth connected"

• When disconnecting a Bluetooth connection: "Bluetooth disconnected"

The Google Assistant button was pressed, but the Google Assistant was not available on the smartphone connected to the headset. "The Google Assistant is not connected"

Precautions

On BLUETOOTH® communications

• Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.

• Bluetooth communications may not be possible, or noise or audio dropout may occur under the following conditions:

- When there is a person between the unit and the Bluetooth device. This situation may be improved by positioning the Bluetooth device so that it faces the antenna of the unit.

- When there is an obstacle, such as a metal object or a wall, between the unit and the Bluetooth device.

- When a Wi-Fi device or microwave oven is in use, or microwaves are emitted near the unit.

- Compared to use indoors, use outdoors is subjected little to signal reflection from walls, floors, and ceilings, which results in audio dropout occurring more frequently than use indoors.

- The antenna is built into the unit as indicated by the dotted line in the illustration below. The sensitivity of the Bluetooth communications can be improved by removing any obstacles between the connected Bluetooth device and the antenna of this unit.

• The situation may be improved by setting the sound quality mode to "priority on stable connection." For details, refer to the Help Guide.

• The situation may be improved by changing the wireless playback quality settings or fixing the wireless playback mode to SBC on the transmitting device. For details, refer to the operating instructions supplied with the transmitting device.

• When listening to music from a smartphone, the situation may be improved by closing unnecessary apps or restarting the smartphone.

• When the outside of the unit is dirty, clean it by wiping with a soft dry cloth. If the unit is particularly dirty, soak a cloth in a dilute solution of neutral detergent, and wipe it well before wiping. Do not use solvents such as thinner, benzene, or alcohol, as they may damage the surface.

• If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

On the use of calling apps for smartphones and computers

• This unit supports normal incoming calls only. Calling apps for smartphones and computers are not supported.

On charging the unit

• This unit can be charged using USB only. A computer with a USB port or a USB AC adaptor is required for charging.

• Be sure to use the supplied USB Type-C cable.

• When charging, the unit cannot be turned on and the Bluetooth function cannot be used.

• If the unit is not used for a long time, the rechargeable battery may become depleted quickly. The battery will be held to a proper charge after it is discharged and recharged several times. When storing the unit for a long time, charge the battery once every six months to prevent over-discharge.

• If the rechargeable battery becomes depleted extremely quickly, it should be replaced with a new one. Please contact your nearest Sony dealer for a battery replacement.

• Position the unit and the Bluetooth device as near as possible to each other.

If you have any questions about this product:

Visit: www.sony.com/support
Contact: Sony Customer Information Service Center at 1-800-222-7669

Write: Sony Customer Information Service Center 12451 Gateway Blvd., Fort Myers, FL 33913

Supplier's Declaration of Conformity

Trade Name : SONY

Model : WH-XB700

Responsible Party : Sony Electronics Inc.

Address : 16535 Via Espriola, San Diego, CA 92127 U.S.A.

Telephone Number : 858-942-2230

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference during a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

• Connection with all Bluetooth devices cannot be guaranteed.

• Bluetooth devices connected with the unit must comply with the Bluetooth standard prescribed by Bluetooth SIG, Inc., and must be certified as compliant.

• Even when a connected device complies with the Bluetooth standard, there may be cases where the characteristics or specifications of the Bluetooth device make it unable to connect, or result in different control methods, display, or operation.

• When using the unit to perform hands-free talking on the phone, noise may occur depending on the connected device or the communication environment.

• Depending on the device to be connected, it may require some time to start communications.

If sound skips frequently during playback

• The situation may be improved by setting the sound quality mode to "priority on stable connection." For details, refer to the Help Guide.

• The situation may be improved by changing the wireless playback quality settings or fixing the wireless playback mode to SBC on the transmitting device. For details, refer to the operating instructions supplied with the transmitting device.

• When listening to music from a smartphone, the situation may be improved by closing unnecessary apps or restarting the smartphone.

• When the outside of the unit is dirty, clean it by wiping with a soft dry cloth. If the unit is particularly dirty, soak a cloth in a dilute solution of neutral detergent, and wipe it well before wiping. Do not use solvents such as thinner, benzene, or alcohol, as they may damage the surface.

• If you experience discomfort while using the unit, stop using it immediately.

• The earpads may be damaged or deteriorate with long-term use and storage.

Cleaning the unit

• When the outside of the unit is dirty, clean it by wiping with a soft dry cloth. If the unit is particularly dirty, soak a cloth in a dilute solution of neutral detergent, and wipe it well before wiping. Do not use solvents such as thinner, benzene, or alcohol, as they may damage the surface.

• If the unit is not used for a long time, the rechargeable battery may become depleted quickly. The battery will be held to a proper charge after it is discharged and recharged several times. When storing the unit for a long time, charge the battery once every six months to prevent over-discharge.

• If the rechargeable battery becomes depleted extremely quickly, it should be replaced with a new one. Please contact your nearest Sony dealer for a battery replacement.

• Position the unit and the Bluetooth device as near as possible to each other.

If the unit does not operate properly

• Follow the procedure below to reset the unit.

Press the and simultaneously while the unit is charging. The unit is reset. When the unit is reset, the pairing information in the unit is deleted.

Charging time:
Approx. 4 hours
(About 90 minutes of music playback is possible after 10 minutes charging.)
Note: Charging and usage hours may be different depending on the conditions of use.

Charging temperature:
5 °C to 35 °C (41 °F to 95 °F)
Mass:
Approx. 195 g (7.68 oz)

Receiver

Impedance:
37 Ω (1 kHz) (when connecting via the headphone cable)

Sensitivity:
103 dB/mW (when connecting via the headphone cable)

Si le son saute fréquemment pendant la lecture

- La situation peut être améliorée en réglant le mode de qualité sonore à « priorité à la connexion stable ». Pour plus de détails, consultez le Manuel d'aide.
- La situation peut être améliorée en modifiant les paramètres de qualité de lecture sans fil ou en réglant le mode de lecture sans fil à SBC sur le périphérique émetteur. Pour plus de détails, consultez le mode d'emploi fourni avec le périphérique émetteur.
- Lorsque vous écoutez de la musique à partir d'un téléphone intelligent, la situation peut être améliorée en fermant les applications inutiles ou en redémarrant le téléphone intelligent.

À propos de l'utilisation des applications d'appel pour les téléphones intelligents et les ordinateurs


- Cet appareil prend seulement en charge les appels entrants normaux. Les applications d'appel pour les téléphones intelligents et les ordinateurs ne sont pas prises en charge.

À propos de la charge de l'appareil

- Cet appareil peut seulement être chargé par USB. Un ordinateur avec un port USB ou un adaptateur CA USB est requis pour la charge.
- Assurez-vous d'utiliser le câble USB Type-C fourni.
- Lors de la charge, l'appareil ne peut pas être mis en marche et la fonction Bluetooth ne peut pas être utilisée.
- Si l'appareil n'est pas utilisé pendant une longue période, la batterie rechargeable peut se vider rapidement. La batterie pourra fournir une charge appropriée après avoir été déchargée et rechargeée plusieurs fois. Lorsque vous rangez l'appareil pendant une longue période, chargez la batterie une fois tous les six mois afin de prévenir la décharge excessive.
- Si la batterie rechargeable se vide très rapidement, elle doit être remplacée par une nouvelle. Veuillez communiquer avec votre détaillant Sony le plus proche pour obtenir une batterie de recharge.

Si l'appareil ne fonctionne pas correctement

- Suivez la procédure ci-dessous pour réinitialiser l'appareil.
- Appuyez simultanément sur les boutons et pendant que l'appareil est en charge. L'appareil est réinitialisé. Après la réinitialisation de l'appareil, les informations de jumelage dans l'appareil sont toujours présentes.



Casque

Source d'alimentation :
3,7 V CC : Batterie rechargeable au lithium-ion intégrée
5 V CC : Lors du chargement par USB

Température de fonctionnement :

0 °C à 40 °C (32 °F à 104 °F)

Consommation électrique nominale :

1,5 W

Nombre d'heures d'utilisation :

Lors de la connexion via le périphérique Bluetooth
Durée de lecture musicale : Max.
30 heures
Durée de communication : Max.
30 heures
Durée de veille : Max. 300 heures

Remarque : Le nombre d'heures d'utilisation peut être inférieur, selon le codec et les conditions d'utilisation.

Durée de chargement :
Environ 4 heures
(Environ 90 minutes de lecture musicale sont possibles après un chargement de 10 minutes.)

Remarque : La durée de chargement et le nombre d'heures d'utilisation peuvent être différents selon les conditions d'utilisation.

Température de chargement :
5 °C à 35 °C (41 °F à 95 °F)

Masse :
Environ 195 g (7,68 oz)

Remarques sur le port de l'appareil

- Comme le casque d'écoute réalise un solide scellement sur les oreilles, appuyer fortement ce dernier contre vos oreilles ou l'enlever rapidement peut entraîner des dommages aux tympans.

Lors du port du casque d'écoute, le diaphragme du haut-parleur pourrait produire un son de déclic. Il ne s'agit pas d'un problème de fonctionnement.

Autres remarques

- Ne soumettez pas l'appareil à un choc excessif.
- Lorsque vous utilisez l'appareil comme un casque d'écoute avec câble, utilisez seulement le câble de casque d'écoute fourni. Assurez-vous que le câble de casque d'écoute est bien inséré.
- La fonction Bluetooth peut ne pas fonctionner avec un téléphone mobile, selon les conditions du signal et l'environnement immédiat.
- N'appliquez pas de pression ou de poids sur l'appareil pendant de longues durées, y compris lorsqu'il est rangé, car cela peut entraîner une déformation.
- Si vous ressentez un inconfort lors de l'utilisation de l'appareil, cessez immédiatement de l'utiliser.
- Les oreillettes peuvent être endommagées ou se détériorer avec l'usage et le rangement prolongés.


Nettoyage de l'appareil

- lorsque l'extérieur de l'appareil est sale, nettoyez-le en l'essuyant avec un chiffon doux et sec. Si l'appareil est particulièrement sale, imbibez un chiffon d'une solution diluée de détergent neutre et essorez-le bien avant d'essuyer l'appareil. N'utilisez pas de solvants tels que du diluant, du benzène ou de l'alcool, car ils pourraient endommager la surface.
- Si vous avez des questions ou des problèmes concernant cet appareil qui ne sont pas abordés dans ce manuel, veuillez consulter votre détaillant Sony le plus proche.

Pièces de rechange : oreillettes

Veuillez consulter votre détaillant autorisé Sony le plus proche ou le site www.sony.com pour plus d'informations sur les pièces de rechange.

Emplacement de l'étiquette du numéro de série



Spécifications

Casque

Source d'alimentation :
3,7 V CC : Batterie rechargeable au lithium-ion intégrée
5 V CC : Lors du chargement par USB

Température de fonctionnement :

0 °C à 40 °C (32 °F à 104 °F)

Consommation électrique nominale :

1,5 W

Nombre d'heures d'utilisation :

Lors de la connexion via le périphérique Bluetooth
Durée de lecture musicale : Max.
30 heures
Durée de communication : Max.
30 heures
Durée de veille : Max. 300 heures

Remarque : Le nombre d'heures d'utilisation peut être inférieur, selon le codec et les conditions d'utilisation.

Durée de chargement :
Environ 4 heures
(Environ 90 minutes de lecture musicale sont possibles après un chargement de 10 minutes.)

Remarque : La durée de chargement et le nombre d'heures d'utilisation peuvent être différents selon les conditions d'utilisation.

Température de chargement :
5 °C à 35 °C (41 °F à 95 °F)

Masse :
Environ 195 g (7,68 oz)

Récepteur

Impédance :
37 Ω (1 kHz) (lors de la connexion via le câble de casque d'écoute)

Sensibilité :
103 dB/mW (lors de la connexion via le câble de casque d'écoute)

Réponse en fréquence :
5 Hz - 22 000 Hz (JEITA)

Éléments inclus :

Casque stéréo sans fil (1)
Câble USB Type-C™ (USB-A à USB-C™) (environ 20 cm (7,88 po)) (1)
Câble de casque d'écoute (environ 1,2 m (47,25 po)) (1)

Spécification de communication

Système de communication :
Spécification Bluetooth version 4.2

Sortie :
Spécification Bluetooth pour classe de puissance 2

Portée de communication maximale :
En ligne directe, environ 10 m (30 pi)¹⁾

Bandes de fréquence :

Bande 2,4 GHz (2,4000 GHz - 2,4835 GHz)

Profils Bluetooth compatibles²⁾ :

A2DP / AVRCP / HFP / HSP

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Profiles Bluetooth compatibles²⁾ :

A2DP / AVRCP / HFP / HSP

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Plage de transmission (A2DP) :

20 Hz - 20 000 Hz (fréquence d'échantillonage de 44,1 kHz)

Codecs pris en charge³⁾ :

SBC / AAC / Qualcomm® aptX™ audio

Pl