





Tefal®


VERSALIO DELUXE








1




2



1




3



4



5




6




7



8



9



10


2



Fry



Deep fry



Fry

0,5 L




Deep fry


2 L



11



12



13




Fry

< 0,5 L



Deep fry

1 L → 2 L




14


3



Deep fry



Max 1000 g




15

16

17



Max 750 g



18

19

20




21

22

23



Deep fry




24




25




26




27




28




29



30



31






32



33



34









5 Deep fry / 180 °C



Deep fry








 2 L maxi			
	1000 g	15-16 min	4
	550 g	10-11 min	
	750 g	13-14 min	
	400 g	7-8 min	



6 Fry / 160 °C



Fry

 0,5 L maxi		
	15 min	4
	30 min	6



7 Sauté / 130 °C



Sauté

x1	10 min	4




8 Simmer / 100 °C



Simmer

30 min	4



9 Boil/Pasta



Boil/Pasta

30 min	4



10 Rice/Risotto



Rice/Risotto

15 min	4



11**Braise**



Braise

40
min


4

52







53




54



55




56




57




58



59



60



61




62



63




64



65


66

67



68


69



70

71

72



73

74


75



76



77



78

79

